

2 Tracks mode

MONO	TRACKS	
	1	2
Input 1	X	X
Input 2	X	X
Input 3	X	X
Input 4	X	X
LEFT / ST / 1-2	X	X
RIGHT / 3-4		

STEREO	TRACKS	
	1	2
Input 1	P	P
Input 2	P	P
Input 3	P	P
Input 4	P	P
LEFT / ST / 1-2	X	
RIGHT / 3-4		X

STEREO Link	TRACKS	
	1	2
Input 1	P	P
Input 2	P	P
Input 3	P	P
Input 4	P	P
LEFT / ST / 1-2	X	X
RIGHT / 3-4		

Two tracks Direct	TRACKS	
	1	2
Input 1	X	
Input 2		X
Input 3		
Input 4		
LEFT / ST / 1-2	X	
RIGHT / 3-4		X

Input 1 > Left Input 2-3-4 > Right	TRACKS	
	1	2
Input 1	X	
Input 2		X
Input 3		X
Input 4		X
LEFT / ST / 1-2	X	
RIGHT / 3-4		X

4 Tracks mode

Four Tracks direct	TRACKS			
	1	2	3	4
Input 1	X			
Input 2		X		
Input 3			X	
Input 4				X
LEFT / ST / 1-2	X	X		
RIGHT / 3-4			X	X

Double STEREO	TRACKS			
	1	2	3	4
Input 1	P	P		
Input 2	P	P		
Input 3			P	P
Input 4			P	P
LEFT / ST / 1-2	X	X		
RIGHT / 3-4			X	X

1-2 > STEREO 3-4 > direct	TRACKS			
	1	2	3	4
Input 1	P	P		
Input 2	P	P		
Input 3			X	
Input 4				X
LEFT / ST / 1-2	X	X		
RIGHT / 3-4			X	X

Software configured

Default configuration

X = connected

Empty = not connected

P = connected through panpot.

Improvements may cause change of features and specifications without notice.

SAS SA

Version: September 24 1998 JS